

Cura 4.0 3D Printing Laboratory Exercises

EXERCISE 3: PREVIEW

1. View types:
 - Click on the first subtab displaying “view types”, and select “Layer view”
2. Color scheme:
 - Click on the second subtab displaying “Color scheme”, and verify that “Material Color” is selected.
3. Slice:
 - After you are satisfy with the print settings, click on the “Slice” button shown on the bottom right of the screen.
 - Fluctuate the side bar located on the right side of the screen. What do you see?
4. Print over the network:
 - This is located on the bottom right of the screen.